


Yealink-Enabling WiFi using a WF50 Dongle

Enabling WiFi using a WF50 Dongle

1. Plug the WF50 dongle into the USB port, usually behind the screen.
2. Go to Menu>Basic>WiFi
 1. For T53, go to Menu>Settings>Basic Settings> WiFi
3. Under WiFi, select On
4. Select Save



[APPLIES TO]

T53 T48S T46S T42S T41S T27G

Version 01.08182021