

Yealink-Enabling WiFi

Enabling WiFi

1. Go to Menu > Basic > WiFi
 1. On the T53W Telephones Go to Menu > Settings > Basic > WiFi
2. Select Available Networks
3. Select Enter
4. Select the desired WiFi network
5. Select Connect.
6. Enter your WiFi password
7. Select OK

Add a Wireless Network Manually

1. Go to Menu > Basic > WiFi
 1. On the T53W Telephones Go to Menu > Settings > Basic > WiFi
2. Select Known Network(s)
3. Select Add
4. Select the Security Mode which matches your WiFi router
5. Enter the WiFi network name and password required to log into your WiFi network
6. Select Save

[APPLIES TO]

VP59 T58A T57W T54W T53W

Version 01.08182021